Order-No.: DD+DIS022.00E

July 2000

1QJQV1
1 Piece QJQ2V MA1

ADC System Components
ID - Station

Installation Instructions

Please file this document in section 3
of your Technical Documentation.

Fresh Installation:

PRID 1.1.05

for the ID-Station

List of Contents

1 General Information 1
1.1 Software Prerequisites 1
1.2 Hardware Prerequisites 1
1.3 Required Time for the Installation 1
1.4 Contents of Delivery Software Kit PRID 1.1.05 1
1.5 Release Environment 2
2 Installation of PRID 1.1.05 3
3 Further Steps for Start up 5
3.1 Install and select the Language File 5
3.2 Install the Configuration File adc.cpf 6
3.3 Adaptation of the Network Settings 7

1 General Information

The “Fresh Installation” is only necessary if you do not purchase the hardware of the Preview- and ID-Station via AGFA.

If purchased via AGFA everything is installed and configured according to the order.

1.1 Software Prerequisites

Preview- and ID-Station:	WINDOWS 95/98 or WINDOWS NT installed.
Processing Station**:**	≥ VIPS 1.0.05
ADC Compact DIGITIZER:	≥ COP_1215 + patch COPA1215; (Order No.: CM+9.5145.1050.2)
ADC Solo DIGITIZER	≥ SOL_1108 + patch SOLD1108; (Order No.: CM+9.5155.1050.2)

1.2 Hardware Prerequisites

see section 14 of your Technical Documentation

1.3 Required Time for the Installation

Less than 15 minutes.

1.4 Contents of Delivery Software Kit PRID 1.1.05

1 x	CD ROM:	PRID 1.1.05
1 x	Floppy disk:	Language files LNG.1.0.05 for PRID ≥ 1.1.05
1 x	User Manual:	User Manual for PRID

1.5 Release Environment

These versions on the hardcopy devices and the IMPAX Stations (and subsequent releases respectively) guarantee that all functions on the PRID Station are supported properly. Other combinations have not been tested and may result in restrictions in functionality.

LR5200	≥ LTP01901
LR5200 Controller	≥ AOS32946/C ≥ CAD32946/C ≥ ECU32947/C
DICOM	≥ DCM2.3.4/C
IMPAX	≥ R3.5_v.2.4.0/C

Connection to third party PACS-systems and printers is continuously enlarged.
Please follow the connectivity release notes to get the latest update.

2 Installation of PRID 1.1.05

- Make sure that the ID-tablet is connected to COM1 of the PC.
- If you are not sure, that the preset ip-address of your PC is used in the local network, disconnect it from the network.

Installation Procedure

No.	Procedure Steps	Display / Comment
1.	• Switch on PC and ID-tablet.	
2.	• Insert CDROM with PRID 1.1.05. The "Install Wizard" starts automatically. If not, eject and insert the CD ROM once again.	The following window appears: `Welcome`
3.	• Click **<Next>**.	The following window appears: `User Information`
4.	• Fill in name and company and click **<Next>**.	The following window appears: `Choose Destination Location`
5.	• Select destination folder c:\prid and click **<Next>**.	The following window appears: `Start Copying Files`
6.	• Click **<Next>**.	Installation starts. The following window appears: `Setup Complete`
7.	• Click **<Finish>**.	A DOS screen appears, before the adc.cpf file will be parsed: `Press any key to continue.`

With WINDOWS 95 close the DOS box manually.

8.	• Press any key to continue	The following window appears: `InstallShield Self-extracting EXE`
9.	• Click **<Yes>** to continue.	The following window appears: `Welcome`
10.	• Click **<Next>**.	The following window appears: `Software License Agreement`
11.	Two cases are possible	
	a) Click **<Yes>**.	
	b) With WINDOWS 95: if asked to install WINSOCK2, answer with **<No>**.	The following window appears: `Select Components`

No.	Procedure Steps	Display / Comment
12.	• Check that both components `program files` and `I18N` are clicked on, then set path to c:\prid\java and click **<Next>**.	The following window may appear: `Question`
13.	• Click **<Yes>** to overwrite the contents of this directory.	The following window appears: `Start Copying Files`
14.	• Click **<Next>**.	The following window appears: `Setup Complete`
15.	• Click **<Finish>**.	
16.	• Eject the CD ROM.	

17.	• Click
	`My computer`
	`Control Panel`
	`Network`	

18.	• Select
	`Protocols`
	`TCP/IP`
	`Properties`
	`IP - address`
		If TCP/IP is not installed, you first have to install it ;
		see section 6.5, DD+DIS 050.99E

19.	• type in the IP address **192.9.200.203** and click **<OK>**	Another IP – address will cause the error message `This is an illegal system` as soon as PRID software is started
20.	• Start the PRID application.	

3 Further Steps for Start up

This chapter describes the following installation steps:

- Install and select the language file
- Install the configuration file adc.cpf.
- Adaptation of IP_address and subnet mask.

3.1 Install and select the Language File

Installation Procedure

No.	Procedure Steps	Display / Comment
1.	• Start the PRID application if not already running	
2.	• Insert the floppy disk with the language files.	

3.	Select from the menu bar
	`Configuration`
	`Change User`
		Window
		`Enter username and password`
		appears

4.	• Change username to service, enter password and hit **<return>**	

5.	Select
	`Configuration`
	`Service`
	`Install languages`
		The window
		`select language*SET file`
		appears

6.	• Choose the source of the language files (floppy drive).	
7.	• Click **<Open>**. .	All language files are loaded

8.	Select
	`Configuration`
	`System Manager`
	`Change language`	

9.	• Choose the customer specific language and click **<Save>**.	
10.	• To make the language active restart the application.	

3.2 Install the Configuration File adc.cpf

The cpf-file with the site specific network addresses incorporated must have been created in advance.

Changing of the cpf-file is only necessary if you integrate into an existing network. With a pure ADC network the default cpf-file (SHIPMENT.CPF) can be used and this installation step 3.2 can be skipped.

No.	Procedure Steps	Display / Comment
1.	• Start the PRID application if not already running	
2.	• Insert the floppy disk with the adc.cpf file.	

3.	Select from the menu bar
	`Configuration`
	`Change User`
		Window
		`Enter username and password` appears

4.	• Change username to service, enter password and hit **`<return>`**	

5.	• Click
	`Configuration`
	`Service`
	`load cpf.file`
		`ADC CPF-file` window appears

6.	• Click `Load/Parse`	The window `Load CPF-file` appears
7.	• choose the source of the adc.cpf file (floppy drive) and click **<open>**	A DOS window appears: `Press any key to continue`
8.	• Press any key.	cpf.file is installed.

3.3 Adaptation of the Network Settings

No.	Procedure Steps	Display / Comment
1.	• Stop the PRID application if running	

2.	• Click
	`My computer`
	`Control Panel`
	`Network`	

3.	• Select
	`Protocols`
	`TCP/IP`
	`Properties`	

4.	• Select `Specify an IP-address`	
5.	• modify ip-address and subnet mask if required and click <OK>	
6.	• shut down the PC and switch it off	
7.	• connect the network cable	
8.	• switch on the PC and start the PRID software	

To check the function of the ID-Station identify a cassette.